## **Technical Data Sheet**

**Product** Mercury Chrome

Codes BS0001

Use A very bright aluminium basecoat with fine particle size and

dark flop effect.

Mix 1 part BS0001 with 1 part TS0001 thinner and mix well.

Preparation Ensure all surfaces to be coated are dry and free from any

contamination. To achieve maximum results, the primer needs to be

smooth and glossy.

Application Use conventional spray application to a dry film thickness of 5-15

microns typically in 2 coats with a 2 minute flash off between coats.

Flash off for 10 minutes before overcoating.

cure Product can be cured up to 200'C depending on the clearcoat used.

If using powder clearcoat, fully bake the basecoat for 20 mins

at 160'C substrate temperature.

Health and

Safety

Always read and understand the appropriate MSDS before

proceeding.

Always check colour and finish before proceeding. Jaytees strive to ensure all information about the product is correct however we have no control over application conditions or equipment. Therefore we cannot accept liability for the performance of the product in service or any loss or damage arising out of use

unless agreed in writing prior to use.