Technical Data Sheet



Product BMW Frozen Gold

Codes **BS0016, BS4152**

Use Solvent based basecoat for wheels

Mix Shake cans well before use.

BS0016 is ready for use.

Mix 4 parts BS4152 with 1 part TS0001 thinner and mix well.

Preparation Ensure all surfaces to be coated are dry and free from any

contamination.

Application Use conventional spray application. Apply over glossy primer.

Warm the wheel to between 60-80 Degrees Centigrade. Apply The BS0016 Bling Chrome in 1-2 coats, taking care not to flood the wheel or apply too dry. Cure the BS0016 before spraying the BS4152 Mid coat. Cool the wheel down to around 60 Degrees Centigrade and apply the BS4152 midcoat in one to 2 coats. Spray to achieve the correct colour. Bake again before applying

satin clearcoat.

cure Product can be cured up to 200'C depending on the clearcoat used.

If using powder clearcoat, fully bake the basecoat for 20 mins

at 160'C substrate temperature.

Health and

Safety

Always read and understand the appropriate MSDS before

proceeding.

Always check colour and finish before proceeding. Jaytees strive to ensure all information about the product is correct however we have no control over application conditions or equipment. Therefore we cannot accept liability for the performance of the product in service or any loss or damage arising out of use unless agreed in writing prior to use.